

Assembly Instructions
3m / 10ft Market Umbrella
with 56 LED Lights

ITM. / ART. # 1902438, 1902386, 1372976, 1902401, 1902352

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY
THE ITEM IS INTENDED FOR OUTDOOR DOMESTIC USE ONLY,
NOT FOR COMMERCIAL USE.



Questions, problems, or missing parts?
Before returning to the store please visit sunvilla.com,
or contact our Customer Service Department
at cs@sunvillahome.com or call

1-888-690-9800

8am - 5pm PST Monday - Friday


Assembly (cont.)

Step 4 - Opening and Closing

Secure the umbrella into an appropriate umbrella base (not included).

Before opening, gently pull apart and separate the umbrella ribs.

Turn the crank handle clockwise and continuing turning until the umbrella is fully opened.



Step 5

Once fully opened, continue turning the crank to tilt the umbrella.


Note: The umbrella will stop tilting at the maximum tilt of 30 degrees. Do not force the crank to continue past this stopping point.



Assembly (cont.)

Step 6 - 360 Degrees Rotation

Pull down the collar to rotate the umbrella 360 degrees. Stop at the desired position and release the collar.



Step 7 - Solar Lights

To turn on and off the solar lights, press on the switch conveniently located near the umbrella crank.

Note: The umbrella must be fully charged before first use. It can be charged with 8 hours of sunlight or 5 hours with the included AC adapter.

For normal operation, turn off the LED's when not in use. Turn off the LED lights to charge the batteries in the daytime.

The battery can be discharged if it is left uncharged for a long period of time. Failure to charge the battery will result in dim lighting.

